



You are in: [International web site](#) Choose a Marzocchi web site

[COMPANY](#) [MTB](#) [MOTO](#) [STORE](#)

[What's New](#) [Products](#) [Technical Area](#) [Bomber Zone](#) [Race](#) [Link](#)



[General warnings](#)

[Tech manuals](#)

[Tuning tips](#)

[FAQ](#)

[Customer Care](#)

Oil level table

[Oil level table](#) | [Air pressure table](#) | [Weights/axle to crown table](#)

MODEL YEAR [1997](#) - [1998](#) - [1999](#) - [2000](#) - [2001](#) - [2002](#) - [2003](#) - [2004](#) - [2005](#) - [2006](#) - [2007](#) - [2008](#)

Note: the table shows the oil volumes in cc. The first number refers to right leg, the second number to left leg.
WARNING: fork oil levels must be adjusted only by Marzocchi Authorized Service Centers.



	55-80 kg	80-90 kg
Jr. T con prolunga MY 1998	160/160	165/165
Jr. T MY 1998	160/160	165/165
Mr. T MY 1998	90/90	95/95
Super T MY 1998	90/90	90/90
Z1 Alloy GT MY 1998	96/96	101/101
Z1 Alloy MY1998	96/96	101/101
Z1 BAM GT MY 1998	96/96	101/101
Z1 BAM MY 1998	96/96	101/101
Z2 Alloy GT MY 1998	80/80	85/85
Z2 Alloy MY 1998	80/80	85/85
Z2 Atom Bomb MY 1998	80/80	85/85
Z2 BAM MY 1998	80/80	85/85
Z3 Alloy MY 1998	65/95	70/100
Z3 Light MY 1998	65/65	70/70

