



TECHNICAL AREA

- ▶ General warnings
- ▶ Tech manuals
- ▶ Oil level table
- ▶ Air pressure table
- ▶ Springs
- ▶ Weights/axle to crown table
- ▶ Travel change table
- ▶ FAQ
 - ▶ General info
 - ▶ Tech info
 - ▶ Maintenance
 - ▶ Glossary
 - ▶ MTB Life
- ▶ Customer care

QUICK LINKS

AIR PRESSURE TABLE

MODEL YEAR: 2006

Note: the table shows the air pressures in PSI (between parenthesis they are expressed in bar).

FORK	RIDER WEIGHT					
	- 55 kg	55-65 kg	65-75 kg	75-85 kg	85-95 kg	+ 95 kg
Z1 FR SL Pos. Air	22 (1.5)	28 (1.9)	34 (2.3)	38 (2.6)	41 (2.8)	45 (3.1)
Z1 FR SL Neg. Air	68 (4.6)	76 (5.2)	85 (5.8)	93 (6.4)	102 (7)	108 (7.4)
Z1 FR SL PAR	0.1	0.3	0.5	0.7	0.9	1.1
ALL MOUNTAIN Pos. Air	22 (1.5)	28 (1.9)	34 (2.3)	38 (2.6)	41 (2.8)	45 (3.1)
ALL MOUNTAIN Neg. Air	68 (4.6)	76 (5.2)	85 (5.8)	93 (6.4)	102 (7)	108 (7.4)
ALL MOUNTAIN PAR	0.1	0.3	0.5	0.7	0.9	1.1
MARATHON SL Pos. Air	26 (1.8)	33 (2.3)	40 (2.8)	44 (3)	48 (3.3)	53 (3.7)
MARATHON SL Neg. Air	90 (6.22)	100 (6.92)	110 (7.61)	120 (8.30)	130 (8.99)	137 (9.48)
MARATHON RACE Pos. Air	28 (1.93)	35 (2.42)	42 (2.90)	46 (3.18)	50 (3.46)	55 (3.80)
MARATHON RACE Neg. Air	80 (5.5)	90 (6.2)	100 (6.8)	110 (7.5)	120 (8.2)	127 (8.7)
MARATHON RACE PAR	0.1	0.3	0.5	0.7	0.9	1.1
MX COMP/COMP ETA Pos. Air	28 (1.9)	36 (2.5)	42 (2.8)	48 (3.3)	52 (3.5)	56 (3.8)
MX PRO Pos. Air	28 (1.9)	36 (2.5)	42 (2.8)	48 (3.3)	52 (3.5)	56 (3.8)
TST System	23 (1.59)	30 (2.07)	37 (2.56)	41 (2.83)	45 (3.11)	50 (3.46)